

Zmena hesla Wi-Fi siete




Manuál pre TP-LINK TL-WR841N

cns.

1. krok: Úvod


- Otvorte si ľubovoľný internetový prehliadač (napríklad Chrome, Firefox , alebo Internet Explorer)
- Do prehliadača zadajte IP adresu **192.168.0.1**
- ak by Vám nezobrazilo prihlasovacie okno, vyskúšajte adresu 192.168.1.1



- Stlačte klávesu Enter

2. krok: Prihlásenie

- Dostávate sa na prihlasovaciu obrazovku do rozhrania Vášho routra, kde je potrebné zadať prihlasovacie meno a heslo
- Vyplňte prihlasovacie meno a heslo – do oboch polí napíšte „admin“ bez úvodzoviek ako vidíte na priloženom obrázku,
 - Prihlasovacie rozhranie sa môže v niektorých prípadoch mierne líšiť od uvedeného príkladu



TP-LINK®

300M Wireless N Router
Model No. TL-WR841N/TL-WR841ND

admin


.....

Login

Copyright © 2014 TP-LINK Technologies Co., Ltd. All rights reserved.

3. krok: Prechod do nastavenia Wi-Fi

- Po prihlásení je potrebné z bočného menu vybrať „Wireless“



The screenshot shows the TP-Link web interface for a 300M Wireless N Router (Model No. TL-WR841N / TL-WR841ND). The left sidebar contains a navigation menu with the following items: Status, Quick Setup, WPS, Network, **Wireless** (highlighted with a red circle), DHCP, Forwarding, Security, Parental Control, Access Control, Advanced Routing, Bandwidth Control, IP & MAC Binding, Dynamic DNS, System Tools, and Logout. The main content area is divided into three sections: Status, LAN, and Wireless. The Status section shows Firmware Version: 3.16.9 Build 150104 Rel.53205n and Hardware Version: WR841N v9 00000000. The LAN section shows MAC Address: C0-4A-00-F1-4D-FC, IP Address: 192.168.0.2, and Subnet Mask: 255.255.255.0. The Wireless section shows Wireless Radio: Enable, Name (SSID): Wifi_hore, Mode: 11bgn mixed, Channel Width: Automatic, Channel: Auto (Current channel 11), and MAC Address: C0-4A-00-F1-4D-FC. A Status Help section on the right provides information about the Status page and lists parameters for LAN and Wireless settings.

TP-LINK® 300M Wireless N Router
Model No. TL-WR841N / TL-WR841ND

Status

Firmware Version: 3.16.9 Build 150104 Rel.53205n
Hardware Version: WR841N v9 00000000

LAN

MAC Address: C0-4A-00-F1-4D-FC
IP Address: 192.168.0.2
Subnet Mask: 255.255.255.0

Wireless

Wireless Radio: Enable
Name (SSID): Wifi_hore
Mode: 11bgn mixed
Channel Width: Automatic
Channel: Auto (Current channel 11)
MAC Address: C0-4A-00-F1-4D-FC

Status Help

The **Status** page displays the Router's current status and configuration. All information is read-only.

LAN - The following parameters apply to the LAN port of the Router. You can configure them in the **Network** -> **LAN** page.

- MAC Address** - The physical address of the Router, as seen from the LAN.
- IP Address** - The LAN IP address of the Router.
- Subnet Mask** - The subnet mask associated with LAN IP address.

Wireless - These are the current settings or information for Wireless. You can configure them in the **Wireless** -> **Wireless Settings** page.

- Wireless Radio** - Indicates whether the wireless radio feature of the Router is enabled or disabled.
- Name (SSID)** - The SSID of the Router.
- Mode** - The current wireless mode which the Router works in.

4. krok: Zmena SSID – pomenovania siete

- Dostávate sa do rozhrania, v ktorom je možné zmeniť názov Vašej siete
- Ak teda chcete zmeniť názov siete, napíšte nový názov do kolonky Wireless Network Name
 - *Ak ste menili názov, uložte Vaše nové nastavenie kliknutím na tlačidlo „Save“*
- Ak názov nechcete meniť, pokračujte na ďalší krok

TP-LINK® 300M Wireless N Router
Model No. TL-WR841N / TL-WR841ND

Wireless Settings

Wireless Network Name: (Also called the SSID)

Region:

Warning: Ensure you select a correct country to conform local law. Incorrect settings may cause interference.

Mode:

Channel Width:

Channel:

Enable Wireless Router Radio
 Enable SSID Broadcast
 Enable WDS Bridging

5. krok: Zmena hesla

- V ľavom menu kliknite na voľbu „Wireless Settings“
- Pre zmenu hesla je potrebné prepísať heslo v riadku „Wireless Password“
 - Heslo musí mať minimálne 8 znakov
- Pokračujte uložením kliknutím na tlačidlo „Save“ v spodnej časti obrazovky
- Router sa reštartuje a heslo je zmenené

The screenshot displays the TP-LINK 300M Wireless N Router web interface. The top header shows the TP-LINK logo and the model number TL-WR841N / TL-WR841ND. The left sidebar contains a navigation menu with the following items: Status, Quick Setup, WPS, Network, Wireless, - Wireless Settings, - Wireless Security (highlighted with a red circle), - Wireless MAC filtering, - Wireless Advanced, - Wireless Statistics, DHCP, Forwarding, Security, Parental Control, Access Control, Advanced Routing, Bandwidth Control, IP & MAC Binding, Dynamic DNS, System Tools, and Logout. The main content area is titled 'Wireless Security' and features three radio button options: 'Disable Security', 'WPA/WPA2 - Personal(Recommended)' (selected), and 'WPA/WPA2 - Enterprise'. Under the selected option, the 'Version' is set to 'WPA2-PSK' and 'Encryption' is set to 'AES'. The 'Wireless Password' field contains the text 'Vaše-heslo' and is highlighted with a red oval. Below this, the 'Group Key Update Period' is set to '0' seconds. The 'WPA/WPA2 - Enterprise' option is also visible with its respective settings.

6. krok: Zmena hesla vo Vašich zariadeniach

- Po zmene mena siete, alebo hesla je samozrejme nutné sa do Vašej Wi-Fi siete prihlásiť s novými prihlasovacími údajmi

